

Product Manual for Pillow Talk - Flirty



Flirty

Flirty should come with a small initial charge and be travel locked out of the box. If it does not have a charge, charge it using instructions in the charging section below.

Travel Lock:

Quickly press the button 3 times until you feel 2 vibrations.

ON/OFF:

Turn the vibrator on by pressing the power button. The LED light will light up when the vibrator is on. While it is on, you can turn it off at any time by pressing the button once.

How to Use:

“Press and Hold” the button to increase the intensity of the vibration.

Cleaning:

There is a cleaning brush included which will help you to properly clean the grooves of the metallic band and around the button.

Note: Pillow Talk™ items are water resistant. Wipe clean with a damp cloth and toy cleaner or warm, soapy water. Do not submerge.

Charging:

Insert the pin of the USB cord into the self-sealing charge port on the side of the product and then plug the USB cord into a USB wall adaptor. While the unit is charging, the LED light will slowly flash. When it has finished charging, the light will be solid. After charging is complete, the product will unlock automatically and be ready for use.

Health and Safety Precautions:

- Do not charge near water.
- Do not charge if the USB cord appears damaged.
- Do not use other USB cords with your product if the one provided is misplaced.
- Do not put the product in the dishwasher or microwave, it will damage your product.
- This product is sold as a novelty only. It is not intended for medical applications or any use that has an adverse effect on any function of the body.
- Use a toy cleaner for all your cleaning needs, before and after use.
- To avoid injury or aggravation of pre-existing physical conditions, this device should not be used on swollen or inflamed areas of skin. Wash before and after use. Do not share with other sexual partners. Help to prevent other sexual diseases through the use of condoms, sexual education, proper judgment and rigorous, diligent care.
- Never let children play with this product.
- In case of pregnancy, diabetes or illness, consult your physician before use.
- When travelling, always make sure this product has been properly turned off and locked.
- Do not use if the silicone appears broken or damaged.
- Only use a water-based lubricant with this product, as silicone-based lubricants have been known to damage silicone products.

Storage:

- Avoid extreme heat.
- When not in use, store this product in a cool, dry place away from the reach of children.

- Keep your product in a dust free location and away from contact with any other similar material or products.

Battery: Lithium 145mAh

Run Time: Up to 2 hours

Vibrating Frequency: 9000 RPM

Output: 3.7V

Weight: 40+/-5g(not including USB cord)

Composition: Silicone, ABS

Charging Time: Approximately 1 hour