

Product Manual for Palmpower Pocket



Run time: Up to 90 minutes

Charge time: 1.5 hours

How to Use:

- To begin, make sure the PalmPower® Pocket is charged.
- If travel lock is enabled, "Press and Hold" the power button down for 3 seconds. You will feel 2 quick vibrations to let you know it is unlocked.
- To turn on, press the button once.
- To cycle through functions, press the button.
- Functions are in the order of low, medium, high, ultra, pulse, rise and tease.
- To turn off, "Press and Hold" the button down for 2 seconds.
- To enable travel lock "Press and Hold" the power button down for 3 seconds. You will feel 2 quick vibrations to let you know it is locked.

Safety Instructions:

- Always unplug this unit from power source before cleaning.
- Do not use near water.
- Only use this product indoors in an open air environment.
- Supervision is necessary when using this product around children or disabled persons.
- Do not let children operate this product.
- Unplug this product when not in use.

- For external use only. NEVER use internally.

Storage:

- Avoid extreme heat.
- When not in use, store this product in a cool, dry place away from the reach of children.
- Keep your product in a dust free location and away from contact with any other similar material or products.

Health and Safety Precautions:

- Do not charge near water.
- Do not charge if the USB cord appears damaged.
- Do not use other USB cords with your product if you have lost the one provided. Contact www.palmpower.ca for more information about adapters. As USB wall charging adapters vary by country, be sure to use the proper one for your area.
- Do not use the product while it is charging.
- Do not put the product in the dishwasher or microwave, it will damage your product.
- Sold as a novelty only. This item is not intended to treat, cure, remedy or correct any pre-existing medical conditions. Not intended for medical applications or any use that has an adverse affect on any function of the body.
- Always use a water based, compatible lubricant with this product for maximum pleasure. To avoid injury or aggravation of pre-existing conditions, this device should not be used on swollen or inflamed areas of the skin. Use a toy cleaner for all your cleaning needs, before and after every use. Do not share with other sexual partners. Help to prevent sexual diseases through the use of proper contraceptives, judgement, education and care.