

Product Manual for BMS – LUX active® – Throb – 4.5" Anal Pulsating Massager – Remote Included



How to Use:

Your Throb should come with a small initial charge and be travel locked out of the box. If it does not have a charge, charge it using the instructions in the charging section below.

The Throb is controlled by one button (figure 1) for travel lock, power, speed and functions.

Travel Lock:

To lock/unlock, press and hold the button for 4 seconds, or until you feel 2 quick pulsations.

ON/OFF:

To turn on, press the button once. The LED Light will light up and stay lit when the Throb is on.

To turn off, press and hold the button for 2 seconds.

Functions:

Quickly press the button to cycle through all 7 dynamic functions of pulsation.

Remote:

The remote controls the Throb with 2 buttons. The top button is for cycling through the functions of pulsation and activating incremental speed control. The bottom button is for bringing you back to the previous function and entering standby mode.

Once the Throb is turned on, quickly press the top button to cycle through all 7 dynamic functions of pulsation. To go back to the first function, press the bottom button once.

Once the Throb is turned on, press and hold the top button to activate incremental speed control. Release the button once you have reached the desired intensity.

To enter standby mode at any time, press and hold the bottom button for 2 seconds.

The remote will not turn off the Throb completely, it will only enter standby mode.

Auto Off:

If the product is left in standby mode without use for more than 10 minutes, it will automatically turn off to preserve battery life.

Cleaning:

It is important to clean your product with toy cleaner before and after every use. To clean, simply spray or pump the cleaner onto a cloth or directly onto the applicable surface, and wipe. Rinse away the cleaner with water and leave the product to air dry.

Always unplug before cleaning and allow to completely dry before use. Do not use any type of solvents such as alcohol or benzene, which may damage not only the finish, but the product itself. To avoid shock, keep the USB cord free from tangling and inspect it for damage frequently.

Charging:

Connect the charger to the magnetic charging contacts on the vibrator. The charger should snap into place. Plug the other end into a USB wall adapter. The LED light will glow indicating that the unit is charging. When the unit is fully charged, the light will disappear. After charging is complete, the Throb will unlock automatically and be ready for use.

If the product will not be used for long periods of time, the battery should be recharged at least once every three months. If possible, avoid fully draining the battery. Charge often between uses to prolong battery life. Only charge with the USB cord provided.

Health and Safety Precautions:

Do not charge near water.

Do not charge if the USB cord appears damaged.

Do not use other USB cords with your product if the one provided is misplaced.

Do not drop on the floor, it will damage your product.

Do not put the product in the dishwasher or microwave, it will damage your product.

This product is sold as a novelty only. It is not intended for medical applications or any use that has an adverse effect on any function of the body.

Use a toy cleaner for all your cleaning needs, before and after use.

To avoid injury or aggravation of pre-existing physical conditions, this device should not be used on swollen or inflamed areas of the skin. Wash before and after use. Do not share with other sexual partners. Help to prevent other sexual diseases through the use of condoms, sexual education, proper judgement and rigorous, diligent care.

Never let children play with this product.

In case of pregnancy, diabetes or illness, consult your physician before use.

Storage:

Avoid extreme heat.

When not in use, store this product in a cool, dry place away from the reach of children.

Specifications:

All Pure Love products are tested for material and electrical safety and are RoHS Compliant and CE Certified.

Battery: Lithium 500mAh

Run Time: Up to 40 minutes

Vibrating Frequency: 240 RPM

Output: 3.7V

Weight: 127.5g (not including USB cord)

Composition: ABS, Silicone

Charging Time: Approximately 2 hours